

ITEM	PART NUMBER	BRAND / ORIGIN	DESCRIPTIONS	
1	BU30	AIWA (SONY) CANNIBALIZE	CD	WITH MECH
2	AP-02	ALPINE ORIGINAL	CAR CD	W/O MECH
3	AP-07	ALPINE ORIGINAL	CAR CD	W/O MECH
4	QSS-100A	CLARION ORIGINAL	CAR CD/VCD/DVD	W/O MECH
5	QSS-200A	CLARION ORIGINAL	CAR CD/VCD/DVD	W/O MECH
6	DSL-710A	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	COMPLETE LOADER SET
7	HOP-1000	HITACHI CANNIBALIZE	CD/VCD/DVD/DVD-ROM	W/O MECH
8	HOP-1000	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
9	HOP-1000	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	WITH MECH
10	HOP-1120	HITACHI CANNIBALIZE	CD/VCD/DVD/DVD-ROM	W/O MECH
11	HOP-1120	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
12	HOP-1161	HITACHI CANNIBALIZE	CD/VCD/DVD/DVD-ROM	W/O MECH
13	HOP-1200N	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
14	HOP-1200R	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
15	HOP-1200S	HITACHI CANNIBALIZE	CD/VCD/DVD/DVD-ROM	W/O MECH
16	HOP-1200S	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
17	HOP-1200S	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	WITH MECH
18	HOP-1200T	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
19	HOP-1200W	HITACHI CANNIBALIZE	CD/VCD/DVD/DVD-ROM	W/O MECH
20	HOP-1200W	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
21	HOP-1201	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
22	HOP-1400	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
23	HOP-1401	HITACHI ORIGINAL	CD/VCD/DVD/DVD-ROM	W/O MECH
24	HOP-3001	HITACHI CANNIBALIZE	CD/VCD/DVD/DVD-ROM	W/O MECH
25	HOP-3001	HITACHI CANNIBALIZE	CD/VCD/DVD/DVD-ROM	WITH MECH
26	HOP-7001	HITACHI ORIGINAL	COMBO-ROM	W/O MECH
27	HOP-7061	HITACHI ORIGINAL	COMBO-ROM	W/O MECH
28	HOP-A1	HITACHI ORIGINAL	CD-ROM	W/O MECH
29	HOP-E1	HITACHI ORIGINAL	CD-ROM	W/O MECH
30	HOP-J15	HITACHI ORIGINAL	UNKNOWN	W/O MECH
31	HOP-M3	HITACHI COMPATIBLE	CD/VCD	W/O MECH
32	HOP-M3A	HITACHI CANNIBALIZE	CD/VCD	WITH MECH
33	HOP-M3A	HITACHI ORIGINAL	CD/VCD	WITH MECH
34	HOP-Z1	HITACHI ORIGINAL	CD-ROM	W/O MECH
35	HOP-R171	HITACHI CANNIBALIZE	COMBO-ROM	W/O MECH
36	HOP-R177G	HITACHI CANNIBALIZE	COMBO-ROM	W/O MECH
37	OPTIMA-150	JVC COMPATIBLE	CD/VCD/SEGA	W/O MECH
38	OPTIMA-4C	JVC ORIGINAL	CD/VCD	W/O MECH
39	OPTIMA-4S	JVC ORIGINAL	CD/VCD	W/O MECH
40	OPTIMA-610	JVC CANNIBALIZE	CAR CD/CD-ROM	W/O MECH
41	OPTIMA-6S	JVC COMPATIBLE	CD/VCD/SEGA	W/O MECH
42	OPTIMA-710	JVC CANNIBALIZE	CAR CD	W/O MECH
43	OPTIMA-715	JVC CANNIBALIZE	CAR CD	W/O MECH
44	OPTIMA-720	JVC COMPATIBLE	CAR CD	W/O MECH
45	OPTIMA-720	JVC ORIGINAL	CAR CD	W/O MECH
46	OPTIMA-725B2	JVC ORIGINAL	CAR CD	W/O MECH
47	OPTIMA-726	JVC ORIGINAL	CAR CD	W/O MECH
48	OPTIMA-7C	JVC ORIGINAL	CD/VCD	W/O MECH
49	OPTIMA-7C	JVC ORIGINAL	CD/VCD	WITH MECH
50	OPTIMA-7S	JVC COMPATIBLE	CD/VCD/SEGA	W/O MECH
51	OPTIMA-7S	JVC ORIGINAL	CD/VCD/SEGA	W/O MECH
52	KCP-1H=H8148AF	KENWOOD COMPATIBLE	CD/VCD	W/O MECH
53	KCP-3H	KENWOOD COMPATIBLE	CD/VCD	W/O MECH
54	KCP-3H	KENWOOD ORIGINAL	CD/VCD	WITH MECH
55	KCP-4C	KENWOOD ORIGINAL	CAR CD/VCD/DVD	W/O MECH
56	KCP-5H	KENWOOD ORIGINAL	CAR CD/VCD/DVD	W/O MECH
57	KCP-6C	KENWOOD ORIGINAL	CAR CD/VCD/DVD	W/O MECH
58	KDP-2H	KEENWOOD ORIGINAL	CD/VCD/DVD	WITH MECH
59	KDP-4H	KEENWOOD ORIGINAL	CD/VCD/DVD	WITH MECH
60	PVR-202T	MITSUMI CANNIBALIZE	CD/VCDDVD	W/O MECH
61	PVR-202T	MITSUMI ORIGINAL	CD/VCDDVD	W/O MECH
62	PVR-302S	MITSUMI ORIGINAL	CD/VCDDVD	W/O MECH
63	PVR-302T	MITSUMI CANNIBALIZE	CD/VCDDVD	W/O MECH
64	PVR-302T	MITSUMI ORIGINAL	CD/VCDDVD	W/O MECH
65	PVR-502T 23P, BIG SOCKET	MITSUMI CANNIBALIZE	CD/VCDDVD	W/O MECH
66	PVR-502W 24P, MINI SOCKET	MITSUMI ORIGINAL	CD/VCDDVD	W/O MECH
67	PVR-502W 24P, MINI SOCKET	MITSUMI ORIGINAL	CD/VCDDVD	WITH MECH
68	PVR-502WGV	MITSUMI ORIGINAL	CD/VCDDVD	WITH MECH
69	PVR-502WGV	MITSUMI ORIGINAL	CD/VCDDVD	W/O MECH
70	PVR-502WSV	MITSUMI ORIGINAL	CD/VCDDVD	W/O MECH
71	PVR-502WSV	MITSUMI ORIGINAL	CD/VCDDVD	WITH MECH
72	PVR-520S	MITSUMI ORIGINAL	CD/VCDDVD	W/O MECH
73	PVR-520T	MITSUMI ORIGINAL	CD/VCDDVD	W/O MECH

74	PVR-520T	MITSUMI ORIGINAL	CD/VCD/DVD	WITH MECH
75	PVR-802W	MITSUMI COMPATIBLE	CD/VCD/DVD/PS2	W/O MECH
76	PVR-802W	MITSUMI COMPATIBLE	CD/VCD/DVD/PS2	WITH MECH
77	PVR-802W	MITSUMI ORIGINAL	CD/VCD/DVD/PS2	W/O MECH
78	PVR-802W	MITSUMI ORIGINAL	CD/VCD/DVD/PS2	WITH MECH
79	PXR-104X	MITSUMI ORIGINAL	CD/VCD	W/O MECH
80	PXR-104X=TCA024X	MITSUMI ORIGINAL	CD/VCD	WITH MECH
81	RAE0111Z	PANASONIC CANNIBALIZE	CD/VCD	W/O MECH
82	RAE0113Z	PANASONIC CANNIBALIZE	CD/VCD	W/O MECH
83	RAE0130Z	PANASONIC ORIGINAL	CD/VCD	W/O MECH
84	RAE0142Z	PANASONIC ORIGINAL	CD/VCD/CAR/CD W/M	W/O MECH
85	RAE0150Z	PANASONIC ORIGINAL	CD/VCD/CAR/CD W/M	W/O MECH
86	RAE0152Z	PANASONIC ORIGINAL	CD/VCD/CAR/CD W/M	W/O MECH
87	RAE0153Z	PANASONIC ORIGINAL	CD/VCD/CAR/CD W/M	W/O MECH
88	RAF0140A	PANASONIC ORIGINAL	CD/VCD/CAR/CD W/M	W/O MECH
89	RAF0140A	PANASONIC BULK NEW	CD/VCD/CAR/CD W/M	W/O MECH
90	RAE0240Z	PANASONIC ORIGINAL	CD/VCD/DVD	W/O MECH
91	RAF-3020A	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
92	RAF-3022A	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
93	RAF-3023A	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
94	RAF-3024A	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
95	VED0383	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
96	VED0402	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
97	VED0403	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
98	VED3020	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
99	VED3022	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
100	VED3023	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
101	VED3024	PANASONIC CANNIBALIZE	CD/VCD/DVD	W/O MECH
102	CDM12.1	PHILIPS COMPATIBLE	CD/VCD	W/O MECH, ROUND LD
103	CDM12.1	PHILIPS COMPATIBLE	CD/VCD	W/O MECH, LINE LD
104	CDM12.1	PHILIPS COMPATIBLE	CD/VCD	WITH MECH, ROUND LD
105	CDM12.3	PHILIPS ORIGINAL BULK NEW	CD/VCD	WITH MECH
106	CDM12.4	PHILIPS CANNIBALIZE	CD/VCD	W/O MECH
107	CDM12.4	PHILIPS CANNIBALIZE	CD/VCD	WITH MECH
108	CDM12.6	PHILIPS COMPATIBLE	CD/VCD	W/O MECH
109	CDM12.6	PHILIPS COMPATIBLE	CD/VCD	WITH MECH
110	CDM9/44	PHILIPS CANNIBALIZE	CD/VCD	WITH MECH
111	CDM9/65	PHILIPS CANNIBALIZE	CD/VCD	WITH MECH
112	RCD1.2	PHILIPS ORIGINAL	CD/VCD	W/O MECH
113	RCD1.3	PHILIPS ORIGINAL	CD/VCD	W/O MECH
114	RCD2	PHILIPS ORIGINAL	CD/VCD	W/O MECH
115	SPU-3110	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
116	SPU-3130	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
117	SPU-3131	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
118	SPU-3134	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
119	SPU-3140	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
120	SPU-3141	PHILIPS CANNIBALIZE	CD/VCD/DVD/XBOX	WITH MECH
121	SPU-3143	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
122	SPU-3150	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
123	SPU-3151	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
124	SPU-3153	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
125	SPU-3160	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
126	SPU-3163	PHILIPS CANNIBALIZE	CD/VCD/DVD	W/O MECH
127	SPU-3170	PHILIPS CANNIBALIZE	CD/VCD/DVD/PS2	W/O MECH
128	SPU-3170	PHILIPS CANNIBALIZE	CD/VCD/DVD/PS2	WITH MECH
129	SPU-3200 16P	PHILIPS CANNIBALIZE	CD-ROM	W/O MECH
130	SPU-3200 17P	PHILIPS CANNIBALIZE	CD-ROM	W/O MECH
131	SPU-3201	PHILIPS CANNIBALIZE	CD-ROM/SEGA	W/O MECH
132	SPU-3230	PHILIPS CANNIBALIZE	CD-ROM/SEGA	W/O MECH
133	VAM1201	PHILIPS COMPATIBLE	CD/VCD	W/O MECH, ROUND LD
134	VAM1202	PHILIPS COMPATIBLE	CD/VCD	W/O MECH, LINE LD
135	VAM1202	PHILIPS COMPATIBLE	CD/VCD	WITH MECH, ROUND LD
136	VAM1202/12	PHILIPS COMPATIBLE	CD/VCD	W/O MECH, LINE LD
137	VAM1202/12	PHILIPS COMPATIBLE	CD/VCD	WITH MECH, LINE LD
138	VAM1202/12	PHILIPS ORIGINAL	CD/VCD	WITH MECH
139	VAM1202J	PHILIPS COMPATIBLE	CD/VCD	WITH MECH, ROUND LD
140	VAM1250	PHILIPS COMPATIBLE	CD/VCD	W/O MECH
141	VAM2201/03	PHILIPS ORIGINAL	CD/VCD	WITH MECH
142	VAM2201/03	PHILIPS ORIGINAL	CD/VCD	W/O MECH, YELLOW PCB
143	VAM2201/07	PHILIPS CANNIBALIZE	CD/VCD	W/O MECH
144	VAM2201/07	PHILIPS ORIGINAL	CD/VCD	WITH MECH
145	VAM2201/07	PHILIPS ORIGINAL	CD/VCD	W/O MECH
146	VAM2201/16	PHILIPS ORIGINAL	CD/VCD	WITH MECH
147	VAM2202/16	PHILIPS ORIGINAL	CD/VCD	WITH MECH

148	VAM2301	PHILIPS CANNIBALIZE	CD/VCD	WITH MECH
149	CXX-1230	PIONEER COMPATIBLE	CAR CD	W/O MECH
150	CXX-1230	PIONEER ORIGINAL	CAR CD	W/O MECH
151	CXX-1235	PIONEER COMPATIBLE	CAR CD	W/O MECH
152	CXX-1235	PIONEER ORIGINAL	CAR CD	W/O MECH
153	CXX-1285	PIONEER COMPATIBLE	CAR CD	W/O MECH
154	CXX-1285	PIONEER ORIGINAL	CAR CD	W/O MECH
155	CXX-1480	PIONEER COMPATIBLE	CAR CD	W/O MECH
156	CXX-1480	PIONEER ORIGINAL	CAR CD	WITH LOADER (COMPLETE SET)
157	CXX-1480	PIONEER ORIGINAL	CAR CD	W/O MECH
158	CXX1550	PIONEER COMPATIBLE	CAR CD	W/O MECH
159	CXX1550	PIONEER ORIGINAL	CAR CD	W/O MECH
160	CXX1639	PIONEER COMPATIBLE	CAR CD	W/O MECH
161	CXX1639	PIONEER ORIGINAL	CAR CD	W/O MECH
162	CXX1641	PIONEER ORIGINAL	CAR CD	W/O MECH
163	CXX1641	PIONEER ORIGINAL	CAR CD	WITH LOADER (COMPLETE SET)
164	CXX-1850	PIONEER ORIGINAL	CAR CD	W/O MECH
165	DWY-1069	PIONEER CANNIBALIZE	DJ MIXER	W/O MECH
166	DWY-1069	PIONEER CANNIBALIZE	CAR CD	W/O MECH
167	GXX1234	PIONEER ORIGINAL	CAR CD	W/O MECH
168	OPU51.61	PIONEER ORIGINAL	CD/VCD/DVD/XBOX DVD-ROM	W/O MECH
169	B31	SAMSUNG COMPATIBLE	CD/VCD	MECH ONLY, NO LENSE
170	MLP-10	SAMSUNG ORIGINAL	CD/VCD	W/O MECH
171	MLP-7	SAMSUNG ORIGINAL	CD/VCD	W/O MECH
172	MLP-9	SAMSUNG ORIGINAL	CD/VCD	W/O MECH
173	SOH-1V1	SAMSUNG ORIGINAL	LD	W/O MECH
174	SOH90-T4N	SAMSUNG ORIGINAL	CD/VCD	W/O MECH
175	SOH-A1U	SAMSUNG COMPATIBLE	CD/VCD	W/O MECH
176	SOH-A2U	SAMSUNG ORIGINAL	CD/VCD	W/O MECH
177	SOH-AAN	SAMSUNG COMPATIBLE	CD/VCD	W/O MECH
178	SOH-AAN	SAMSUNG COMPATIBLE	CD/VCD	WITH MECH
179	SOH-AAU	SAMSUNG COMPATIBLE	CD/VCD	W/O MECH
180	SOH-AAV	SAMSUNG ORIGINAL	CD/VCD	WITH MECH
181	SOH-AAX	SAMSUNG ORIGINAL	CD/VCD	WITH MECH
182	SOH-AD3	SAMSUNG COMPATIBLE	CD/VCD	W/O MECH
183	SOH-AD3U	SAMSUNG COMPATIBLE	CD/VCD	W/O MECH
184	SOH-ADU	SAMSUNG COMPATIBLE	CD/VCD	W/O MECH
185	SOH-AP	SAMSUNG CANNIBALIZE	CD/VCD	W/O MECH
186	SOH-AP	SAMSUNG COMPATIBLE	CD/VCD	W/O MECH
187	SOH-APU	SAMSUNG COMPATIBLE	CD/VCD	W/O MECH
188	SOH-D12	SAMSUNG CANNIBALIZE	CD/VCD/DVD/XBOX DVD-ROM	W/O MECH
189	SOH-D16	SAMSUNG CANNIBALIZE	CD/VCD/DVD/XBOX DVD-ROM	W/O MECH
190	SOH-D21U	SAMSUNG CANNIBALIZE	CD/VCD/DVD	W/O MECH
191	SOH-D21U	SAMSUNG CANNIBALIZE	CD/VCD/DVD	WITH MECH
192	SOH-D21U	SAMSUNG ORIGINAL	CD/VCD/DVD	WITH MECH
193	SOH-DBU1	SAMSUNG ORIGINAL	CD/VCD/DVD	WITH MECH
194	SOH-DH2	SAMSUNG CANNIBALIZE	CD/VCD/DVD	W/O MECH
195	SOH-DH2	SAMSUNG CANNIBALIZE	CD/VCD/DVD	WITH MECH
196	SOH-DL2D	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
197	SOH-DL3D	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
198	SOH-DL3C	SAMSUNG ORIGINAL	CD/VCD/DVD	WITH MECH
199	SOH-DL3C	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
200	SOH-DL3CH	SAMSUNG ORIGINAL	CD/VCD/DVD	WITH MECH
201	SOH-DL3CH	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
202	SOH-DL3E	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
203	SOH-DM2	SAMSUNG ORIGINAL	CD/VCD/DVD	WITH MECH
204	SOH-DM2A	SAMSUNG ORIGINAL	CD/VCD/DVD	WITH MECH
205	SOH-DMZU	SAMSUNG ORIGINAL	CD WALKMAN	WITH MECH
206	SOH-DP1U	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
207	SOH-DR16S	SAMSUNG ORIGINAL	UNKNOWN	W/O MECH
208	SOH-DS2A	SAMSUNG CANNIBALIZE	CD/VCD/DVD	W/O MECH, FULL TEST
209	SOH-DS2B	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
210	SOH-DSSB	SAMSUNG COMPATIBLE	CD/VCD/DVD	W/O MECH
211	SOH-DT2	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
212	SOH-DTH2=SOH-DT2	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
213	SOH-DV1U	SAMSUNG ORIGINAL	CD/VCD/DVD	W/O MECH
214	SOH-DX1	SAMSUNG ORIGINAL	CD/VCD/DVD/XBOX DVD-ROM	W/O MECH
215	SOH-M95	SAMSUNG ORIGINAL	CD WALKMAN	WITH MECH
216	SOH-M96	SAMSUNG ORIGINAL	CD WALKMAN	WITH MECH
217	SOH-DW12	SAMSUNG ORIGINAL	DVD-ROM	W/O MECH
218	DM23	SANYO ORIGINAL	CD WALKMAN	WITH MECH
219	DV-34	SANYO ORIGINAL	CD/VCD/DVD	WITH MECH
220	SF-87	SANYO CANNIBALIZE	CD/VCD/CAR CD	W/O MECH
221	SF-89S	SANYO CANNIBALIZE	CD/VCD/CAR CD	W/O MECH

222	SF-90 5/6P	SANYO CANNIBALIZE	CD/VCD	W/O MECH
223	SF-90 5/8P CABLE	SANYO COMPATIBLE	CD/VCD	W/O MECH
224	SF-90 6/6P	SANYO CANNIBALIZE	CD/VCD	W/O MECH
225	SF-90 6/7P	SANYO CANNIBALIZE	CD/VCD	W/O MECH
226	SF-90 6/8P	SANYO CANNIBALIZE	CD/VCD	W/O MECH
227	SF-91 5/6P	SANYO CANNIBALIZE	CD/VCD	W/O MECH
228	SF-91 5/8P	SANYO COMPATIBLE	CD/VCD	W/O MECH
229	SF-92.5 4/11P	SANYO COMPATIBLE	CAR CD	W/O MECH
230	SF-92.5 4/12P	SANYO COMPATIBLE	CAR CD	W/O MECH
231	SF-92.5 SINGLE CABLE	SANYO CANNIBALIZE	CAR CD/CD WALKMAN	W/O MECH
232	SF-C20	SANYO CANNIBALIZE	CAR CD	W/O MECH, METAL/PLASTIC COVER
233	SF-C20	SANYO ORIGINAL	CAR CD	W/O MECH, PLACTIC COVER
234	SF-C20	SANYO ORIGINAL	CAR CD	W/O MECH, METAL COVER
235	SF-C93 2P	SANYO COMPATIBLE	CAR CD	W/O MECH
236	SF-C93 4P	SANYO COMPATIBLE	CAR CD	W/O MECH
237	SF-C94	SANYO COMPATIBLE	CAR CD	W/O MECH
238	SF-C99	SANYO COMPATIBLE	CAR CD	W/O MECH
239	SF-C99	SANYO ORIGINAL	CAR CD	W/O MECH
240	SF-DB10S	SANYO CANNIBALIZE	DVD-RW-ROM	W/O MECH, ; 60-70% WARRANTEE
241	SF-DB11S	SANYO CANNIBALIZE	DVD-RW-ROM	W/O MECH, ; 60-70% WARRANTEE
242	SF-DA50	SANYO ORIGINAL	CD WALKMAN	WITH MECH
243	SF-DV21	SANYO ORIGINAL	DVD-RW-ROM	WITH MECH
244	SF-HD3 BIG PCB	SANYO ORIGINAL	CD/VCD/DVD	W/O MECH
245	SF-HD3 BIG PCB	SANYO ORIGINAL	CD/VCD/DVD	WITH MECH
246	SF-HD3 MINI PCB	SANYO ORIGINAL	CD/VCD/DVD	W/O MECH
247	SF-HD3 MINI PCB	SANYO ORIGINAL	CD/VCD/DVD	WITH MECH
248	SF-HD4	SANYO ORIGINAL	CAR CD/CD/VCD/DVD	W/O MECH
249	SF-HD6	SANYO ORIGINAL	CD/VCD/DVD	W/O MECH
250	SF-HD6	SANYO ORIGINAL	CD/VCD/DVD	WITH MECH
251	SF-HD60	SANYO COMPATIBLE	CD/VCD/DVD	W/O MECH
252	SF-HD60	SANYO COMPATIBLE	CD/VCD/DVD	WITH MECH
253	SF-HD60	SANYO ORIGINAL	CD/VCD/DVD	W/O MECH
254	SF-HD60	SANYO ORIGINAL	CD/VCD/DVD	WITH MECH
255	SF-HD62	SANYO COMPATIBLE	CD/VCD/DVD	WITH MECH
256	SF-HD62	SANYO COMPATIBLE	CD/VCD/DVD	W/O MECH
257	SF-HD63	SANYO ORIGINAL	CD/VCD/DVD	W/O MECH
258	SF-HD63	SANYO ORIGINAL	CD/VCD/DVD	WITH MECH
259	SF-HD65	SANYO ORIGINAL	CD/VCD/DVD	W/O MECH
260	SF-HD65	SANYO COMPATIBLE	CD/VCD/DVD	WITH MECH
261	SF-HD66	SANYO CANNIBALIZE	CD/VCD/DVD	W/O MECH
262	SF-HD66	SANYO CANNIBALIZE	CD/VCD/DVD	WITH MECH
263	SF-HD67	SANYO ORIGINAL	XBOX360 DVD-ROM	W/O MECH
264	SF-HD68	SANYO ORIGINAL	CD/VCD/DVD	W/O MECH
265	SF-HD7	SANYO REPAIRED	PS2 DVD-ROM	W/O MECH
266	PS400H=Sf-HD7	SANYO COMPATIBLE	PS2 DVD-ROM	W/O MECH
267	SF-HD8	SANYO ORIGINAL	DVD-ROM/CAR CD/DVD	WITH MECH
268	SF-HD80	SANYO ORIGINAL	CD-VCD-DVD	W/O MECH
269	SF-P1 13P	SANYO CANNIBALIZE	CD/VCD	W/O MECH, SOCKET TYPE
270	SF-P1 6/6P	SANYO CANNIBALIZE	CD/VCD	W/O MECH, CABLE TYPE
271	SF-P100 13P BIG PCB	SANYO COMPATIBLE	CD/VCD/CD-ROM	W/O MECH
272	SF-P100 13P MINI PCB	SANYO ORIGINAL	CD/VCD/CD-ROM	W/O MECH
273	SF-P101 15P	SANYO COMPATIBLE	CD/VCD	W/O MECH
274	SF-P101 5/8P	SANYO COMPATIBLE	CD/VCD	W/O MECH
275	SF-P101 5/8P	SANYO COMPATIBLE	CD/VCD	WITH MECH
276	SF-P101N 15P	SANYO CANNIBALIZE	CD/VCD	W/O MECH
277	SF-P101N 15P	SANYO CANNIBALIZE	CD/VCD	WITH MECH
278	SF-P101N 15P	SANYO COMPATIBLE	CD/VCD	W/O MECH
279	SF-P101N 15P	SANYO COMPATIBLE	CD/VCD	WITH MECH
280	SF-P101N 16P	SANYO ORIGINAL	CD/VCD	W/O MECH
281	SF-P101N 16P	SANYO ORIGINAL	CD/VCD	WITH MECH
282	SF-P102 16P = SF-P101N 16P	SANYO ORIGINAL	CD/VCD	W/O MECH
283	SF-P151 16P	SANYO ORIGINAL	CD/VCD/CD-ROM	W/O MECH
284	SF-P151 17P	SANYO ORIGINAL	CD/VCD/CD-ROM	W/O MECH
285	SF-P200(DA23)	SANYO ORIGINAL	CD WALKMAN	WITH MECH
286	SF-P200(DA23)	SANYO ORIGINAL	CD WALKMAN	W/O MECH
287	SF-U3000 17P	SANYO CANNIBALIZE	CAR CD	W/O MECH
288	SF-U3000 18P	SANYO CANNIBALIZE	CAR CD	W/O MECH
289	SF-U5000	SANYO CANNIBALIZE	CAR CD	W/O MECH
290	SF-W03	SANYO CANNIBALIZE	CD-RW-ROM	W/O MECH
291	SF-W32	SANYO CANNIBALIZE	CD-RW-ROM	W/O MECH
292	SF-W33	SANYO CANNIBALIZE	CD-RW-ROM	W/O MECH
293	SF-W34	SANYO CANNIBALIZE	CD-RW-ROM	W/O MECH
294	SF-W35	SANYO CANNIBALIZE	CD-RW-ROM	W/O MECH
295	SF-W36	SANYO CANNIBALIZE	DVD-RW-ROM	W/O MECH; 60-70% WARRANTEE

296	SF-W37	SANYO CANNIBALIZE	DVD-RW-ROM	W/O MECH; 60-70% WARRANTY
297	H8141AF	SHARP COMPATIBLE	CD/VCD	W/O MECH
298	H8146AF	SHARP CANNIBALIZE	CD/VCD	W/O MECH
299	H8147AF	SHARP CANNIBALIZE	CD/VCD	W/O MECH
300	H8147AF	SHARP COMPATIBLE	CD/VCD	W/O MECH
301	H8148AF=KCP-1H	SHARP COMPATIBLE	CD/VCD	W/O MECH
302	H8151AF=HPC-1L	SHARP COMPATIBLE	CD/VCD	W/O MECH
303	H8175AF	SHARP ORIGINAL	MD-ROM	W/O MECH
304	HPC-1L=H8151AF	SHARP COMPATIBLE	CD/VCD	W/O MECH
305	HPC-1L=H8151AF	SHARP ORIGINAL	CD/VCD	WITH MECH
306	HPC-1LF=HPC-3LX	SHARP COMPATIBLE	CD/VCD	W/O MECH
307	HPC-1LX	SHARP COMPATIBLE	CD/VCD	W/O MECH
308	HPC-1LX	SHARP ORIGINAL	CD/VCD	WITH MECH
309	HPC-1MX	SHARP COMPATIBLE	CD/VCD	W/O MECH
310	HPC-1UM	SHARP COMPATIBLE	CD/VCD	W/O MECH
311	HPC-3LX=HPC-1LF	SHARP COMPATIBLE	CD/VCD	W/O MECH
312	HPD-10VF	SHARP REPAIRED	CAR CD/CD/VCD/DVD	W/O MECH
313	HPD-40	SHARP ORIGINAL	CAR CD/CD/VCD/DVD	W/O MECH
314	HPD-50	SHARP ORIGINAL	CAR CD/CD/VCD/DVD	W/O MECH
315	HPD-52	SHARP ORIGINAL	CAR CD/CD/VCD/DVD	WITH MECH
316	HPD-52	SHARP ORIGINAL	CAR CD/CD/VCD/DVD	W/O MECH
317	DAX-11	SONY CANNIBALIZE	CD WALKMAN	W/O MECH
318	BU21	SONY ORIGINAL	CD/VCD/DVD	WITH MECH
319	DAX-23E	SONY ORIGINAL	CD WALKMAN	W/O MECH
320	DAX-25 2/2P	SONY CANNIBALIZE	CD WALKMAN	WITH MECH
321	DAX-25 2/4P	SONY CANNIBALIZE	CD WALKMAN	WITH MECH
322	DBU-1	SONY ORIGINAL	CD/VCD/DVD	WITH MECH
323	IDP200A	SONY ORIGINAL	CD/VCD/DVD	WITH MECH
324	KHM210AAA	SONY CANNIBALIZE	CD/VCD/DVD	WITH MECH
325	KHM220AAA	SONY ORIGINAL	CD/VCD/DVD	WITH MECH
326	KHM230AAA	SONY CANNIBALIZE	CD/VCD/DVD	WITH MECH
327	KHM234ASAA	SONY CANNIBALIZE	CD/VCD/DVD	WITH MECH
328	KHM240AAA	SONY CANNIBALIZE	CD/VCD/DVD	WITH MECH
329	KHM250AAA	SONY CANNIBALIZE	CD/VCD/DVD	WITH MECH
330	KHM270AAA	SONY CANNIBALIZE	CD/VCD/DVD	WITH MECH
331	KHM280AAA	SONY CANNIBALIZE	CD/VCD/DVD	WITH MECH
332	KHM290AAA	SONY ORIGINAL	CD/VCD/DVD	WITH MECH
333	KHM310AAA	SONY CANNIBALIZE	CD/VCD/DVD	WITH MECH
334	KHM310AAA	SONY ORIGINAL	CD/VCD/DVD	WITH MECH
335	KHM310AHC	SONY ORIGINAL	CD/VCD/DVD	WITH MECH
336	KHM313AAA	SONY ORIGINAL	CD/VCD/DVD	WITH MECH
337	KHM430	SONY ORIGINAL BULK NEW	PS2 DVD-ROM	W/O MECH, FULL TEST
338	KHM430	SONY ORIGINAL BULK NEW	PS2 DVD-ROM	WITH MECH, FULL TEST
339	KHS130A	SONY ORIGINAL	LD	W/O MECH
340	KHS150A	SONY ORIGINAL	LD	W/O MECH
341	KHS400A	SONY REPAIRED	PS2 DVD-ROM	W/O MECH
342	KHS400B	SONY REPAIRED	PS2 DVD-ROM	W/O MECH
343	KHS400C	SONY REPAIRED	PS2 DVD-ROM	W/O MECH
344	PS400Q=KHS400C	SONY COMPATIBLE	PS2 DVD-ROM	W/O MECH, BRAND NEW
345	KHS400R	SONY REPAIRED	PS2 DVD-ROM	W/O MECH
346	PS400H=KHS400R	SONY COMPATIBLE	PS2 DVD-ROM	W/O MECH, BRAND NEW
347	KRS-220B	SONY CANNIBALIZE	CD-RW-ROM	W/O MECH
348	KRS-220C	SONY ORIGINAL	CD-RW-ROM	W/O MECH
349	KRS-340B	SONY CANNIBALIZE	CD-RW-ROM	W/O MECH
350	KRS-350B	SONY CANNIBALIZE	CD-RW-ROM	W/O MECH
351	KRS-360B	SONY CANNIBALIZE	CD-RW-ROM	W/O MECH
352	KWS-252A	SONY CANNIBALIZE	DVD-RW-ROM	W/O MECH
353	KSM213CCM	SONY COMPATIBLE	CD/VCD	MECH ONLY, NO LENSE
354	KSM213CCM	SONY COMPATIBLE	CD/VCD	WITH MECH
355	KSM213CCM	SONY ORIGINAL	CD/VCD	WITH MECH
356	KSM213CDM	SONY COMPATIBLE	CD/VCD	WITH MECH
357	KSM213DHAP	SONY COMPATIBLE	CD/VCD	WITH MECH
358	KSM213QCS	SONY ORIGINAL	CD/VCD	WITH MECH
359	KSM213VSCM	SONY COMPATIBLE	CD/VCD	WITH MECH
360	KSM215CFP	SONY CANNIBALIZE	CD/VCD	WITH MECH
361	KSM215DCP	SONY CANNIBALIZE	CD/VCD	WITH MECH
362	KSM310AAA	SONY CANNIBALIZE	CAR CD	WITH MECH
363	KSM310AAA	SONY CANNIBALIZE	CAR CD	WITH MECH, LOADER
364	KSM440ADM	SONY COMPATIBLE	PS1 CD-ROM	WITH MECH
365	KSM440AEM	SONY COMPATIBLE	PS2 CD-ROM	WITH MECH
366	KSM440BAM	SONY COMPATIBLE	PS3 CD-ROM	WITH MECH
367	KSM542A	SONY ORIGINAL	CAR CD	WITH MECH
368	KSM620AAA	SONY ORIGINAL	CD WALKMAN	WITH MECH
369	KSM770AAA	SONY ORIGINAL	CD/VCD/ CAR CD	WITH MECH

370	KSM770AAA	SONY ORIGINAL	CD/VCD/ CAR CD	WITH MECH, LOADER
371	KSM770ACA	SONY ORIGINAL	CD/VCD/ CAR CD	WITH MECH
372	KSM770ACA	SONY ORIGINAL	CD/VCD/ CAR CD	WITH MECH, LOADER
373	KSM780AAA	SONY ORIGINAL	CD WALKMAN	WITH MECH
374	KSM900AAA	SONY ORIGINAL	CD WALKMAN	WITH MECH
375	KSM910AAA	SONY ORIGINAL	CD WALKMAN	WITH MECH
376	KSS1000AAA	SONY CANNIBALIZE	CD WALKMAN	WITH MECH
377	KSS1000ABA	SONY CANNIBALIZE	CD WALKMAN	WITH MECH
378	KSS1000E	SONY COMPATIBLE	CAR CD	W/O MECH
379	KSS1000E	SONY ORIGINAL	CAR CD	W/O MECH
380	KSS151A	SONY ORIGINAL	CD/VCD	W/O MECH
381	KSS210A	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
382	KSS210B	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
383	KSS212A	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
384	KSS212B	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
385	KSS240A	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B, G/S
386	KSS240A	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B, W/S
387	KSS213Q	SONY ORIGINAL	CD/VCD	W/O MECH
388	KSS213R	SONY ORIGINAL	CD/VCD	W/O MECH
389	KSS240A	SONY CANNIBALIZE	CD/VCD	W/O MECH
390	KSS213A	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
391	KSS213B	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
392	KSS213C	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
393	KSS213C	SONY ORIGINAL	CD/VCD	W/O MECH
394	KSS213D	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
395	KSS213E	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
396	KSS213F	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
397	KSS213Q	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
398	KSS213V	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
399	KSS213VL	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
400	KSS213VS	SONY COMPATIBLE	CD/VCD	W/O MECH, BLU LENS, M/B
401	KSS213A	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
402	KSS213B	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
403	KSS213C	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
404	KSS213D	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
405	KSS213E	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
406	KSS213F	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
407	KSS213Q	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
408	KSS213V	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
409	KSS213VL	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
410	KSS213VS	SONY COMPATIBLE	CD/VCD	W/O MECH, BLK LENS, M/B
411	KSS310A	SONY CANNIBALIZE	CAR CD	W/O MECH
412	KSS313A	SONY COMPATIBLE	CAR CD	W/O MECH
413	KSS313C	SONY COMPATIBLE	CAR CD	W/O MECH
414	KSS314A	SONY COMPATIBLE	CAR CD	W/O MECH
415	KSS315A	SONY COMPATIBLE	CAR CD	W/O MECH
416	KSS320A	SONY COMPATIBLE	CAR CD	W/O MECH
417	KSS320C	SONY COMPATIBLE	CAR CD	W/O MECH
418	KSS330A	SONY COMPATIBLE	CD/VCD/CD-ROM	W/O MECH
419	KSS331A	SONY COMPATIBLE	CAR CD	W/O MECH
420	KSS331C	SONY COMPATIBLE	CAR CD	W/O MECH
421	KSS360	SONY CANNIBALIZE	CD/VCD/CD ROM	W/O MECH
422	KSS520A	SONY ORIGINAL	CAR CD	W/O MECH
423	KSS520A	SONY COMPATIBLE	CAR CD	W/O MECH
424	KSS540A	SONY CANNIBALIZE	CAR CD	WITH LOADER (COMPLETE SET)
425	KSS542A	SONY ORIGINAL	CAR CD/ CD WALKMAN	W/O MECH
426	KSS542A	SONY ORIGINAL	CAR CD/ CD WALKMAN	WITH MECH
427	KSS585	SONY CANNIBALIZE	CD ROM	W/O MECH
428	KSS575B	SONY ORIGINAL	CD ROM	W/O MECH
429	KSS620A	SONY ORIGINAL	CD WALKMAN	W/O MECH
430	KSS660	SONY ORIGINAL	CAR CD	W/O MECH
431	KSS710A	SONY ORIGINAL	CAR CD	W/O MECH
432	KSS711A	SONY ORIGINAL	CAR CD	W/O MECH
433	KSS720A	SONY REPAIRED	CAR CD	W/O MECH
434	KSS720A=KSS721A	SONY COMPATIBLE	CAR CD	W/O MECH
435	KSS720A=KSS721A	SONY ORIGINAL	CAR CD	W/O MECH
436	KSS721A	SONY COMPATIBLE	CAR CD	W/O MECH
437	KSS721A	SONY ORIGINAL	CAR CD	W/O MECH
438	KSS910	SONY ORIGINAL	CAR CD	W/O MECH
439	DOP-110B	THOMSON CANNIBALIZE	CD/VCD	W/O MECH
440	TCM125	THOMSON CANNIBALIZE	CD/VCD	WITH MECH, WITH BOARD
441	TCM125	THOMSON ORIGINAL	CD/VCD	WITH MECH, WITH BOARD
442	TCM130	THOMSON CANNIBALIZE	CD/VCD	WITH MECH, WITH BOARD
443	TCM130-2L	THOMSON ORIGINAL	CD/VCD	WITH MECH, WITH BOARD

444	TCM133	THOMSON ORIGINAL	CD/VCD	WITH MECH , WITH BOARD
445	TCM135-2	THOMSON CANNIBALIZE	CD/VCD	WITH MECH, WITH BOARD
446	TCM135-2	THOMSON ORIGINAL	CD/VCD	WITH MECH, WITH BOARD
447	TCM135-5	THOMSON CANNIBALIZE	CD/VCD	WITH MECH, WITH BOARD
448	TCM135-5	THOMSON ORIGINAL	CD/VCD	WITH MECH, WITH BOARD
449	TCM165-2	THOMSON ORIGINAL	CD/VCD	WITH MECH, WITH BOARD
450	TCP11SK	THOMSON CANNIBALIZE	CD/VCD	WITH MECH
451	TCP11SL	THOMSON CANNIBALIZE	CD/VCD	WITH MECH
452	TCP11TK	THOMSON CANNIBALIZE	CD/VCD	WITH MECH
453	TCP11TM2P	THOMSON CANNIBALIZE	CD/VCD	WITH MECH
454	TCP11VK	THOMSON CANNIBALIZE	CD/VCD	WITH MECH
455	TOP60	THOMSON CANNIBALIZE	CD/VCD/DVD/XBOX	W/O MECH
456	TPP35B	THOMSON ORIGINAL	CD WALKMAN	WITH MECH
457	TVM506R3	THOMSON ORIGINAL	CD/VCD/DVD	WITH MECH, BOARD
458	TVM506R6	THOMSON ORIGINAL	CD/VCD/DVD	WITH MECH, BOARD
459	TVP503R3	THOMSON ORIGINAL	CD/VCD/DVD	WITH MECH, BOARD
460	APU-0201	TOSHIBA ORIGINAL	CD/VCD/DVD	W/O MECH
461	APU-2010	TOSHIBA ORIGINAL	CD/VCD/DVD	W/O MECH
462	APU-3100	TOSHIBA CANNIBALIZE	CD/VCD/DVD	W/O MECH
463	APU-3101	TOSHIBA CANNIBALIZE	CD/VCD/DVD	W/O MECH
464	KP-1	TOSHIBA ORIGINAL	CD/VCD	W/O MECH
465	OPC-A15-1	JIANG HAI ORIGINAL	CD/VCD	WITH MECH

<http://www.partmate.com>